VITEK

VITEK
INDUSTRIAL VIDEO PRODUCTS, INC.

VT-H41

4 Channel Digital Video Recorder with H.264 Compression

- 4 Video Inputs with 1 BNC & 1 VGA Outputs
- H.264 Compression
- Supports both Dynamic and Static IP Addresses
- Up to 120 IPS Recording / Live Display
- Remote Viewing over the Internet or LAN
- Supports one internal SATA Hard Drive
- 250GB to 1TB Internal Storage Options
- Quadplex operation enabling simultaneous recording, playback, networking, and backup
- 4 Alarm Inputs / 1 Relay Out
- 4 Audio Inputs & 1 Output
- PTZ Control over RS-485
- Control locally via Included IR Remote control, or Front Panel Controls
- Backup via Ethernet or USB

SAFETY PRECAUTIONS


CAUTION
RISK OF ELECTRIC SHOCK
DO NOT OPEN
CAUTION : TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

EXPLANATION OF SYMBOLS

This symbol is intended to alert the user to the presence of important operation and maintenance (servicing) instructions in the literature accompanying the appliance.

This symbol is intended to alert the user to the presence of unprotected "dangerous voltage" within the product's enclosure that may be strong enough to cause a risk of electric shock

WARNING

To reduce the risk of fire or electric shock, do not expose this product to rain or moisture.

CAUTION

Changes or modifications not expressly approved by the manufacturer may void the user's authority to operate this equipment.

CAUTION

Danger of explosion if battery is incorrectly replaced.

Replace only with the same or equivalent type recommended by the manufacturer.

WARNING

- Do not use if the unit emits smoke, strange sounds are heard, or odor is emitted.
- Make sure the power cable is not damaged.
- Make sure there is no dust accumulation on the power plug or the outlet.
- Disassembly prohibited
- Do not place any foreign objects inside the unit.

- Do not place a container holding water or other liquids above the unit when it is connected to power.
- Do not allow the unit to get wet.
- Do not use during thunder/thunder storms unless used with an uninterruptable power supply (UPS).
- Do not place in an unstable position.
- Do not expose to shock or vibration.
- Do not use this unit in areas where it is exposed to the possibility of explosion.

CAUTION

- Do not pull on the power cable when removing the power plug from the outlet.
- Do not touch the power plug with wet hands.
- Do not sit on.
- Make sure the cables are connected properly.
- Do not place heavy objects on connected units.
- Never move this unit while the power is turned on.
- Do not block the cooling fans or air ducts.
- Do not expose to extreme temperatures or humidity changes.

Precautions for supplied AC Adaptor

CAUTION

- Never disassemble or modify.
- Never get the adaptor wet.
- Never disassemble or modify.
- Never get the adaptor wet.
- Use only the supplied AC adapter.
- Do not connect to other appliances.
- Do not connect this unit with the AC adapter in areas reachable to children or where pets move freely.
- Never touch the AC adapter with wet hands.
- If the unit emits smoke, strange sounds or smells immediately remove the AC adapter from the outlet.
- Do not use during thunder/thunder storms unless used with an uninterruptable power supply (UPS).
- Make sure the cable is connected properly to prevent damage to the cable.

Main features

- H.264 Video compression



- QUADPLEX operation enabling simultaneous recording, playback, networking, and backup.



- Instant and convenient data backup & firmware upgrade using USB flash drive

  Simple User Interface



- Individual channel setting and operation
- Motion detection record



- Free Dynamic DNS

System components and Installation

Requirements for installation and safety

This chapter is for the requirements for safe installation and use.

This kit should be installed on a flat table or in a rack.

The location in which the DVR is installed in the room is very important for proper operation of the system. When the DVR is installed too closely together or the location is poorly ventilated, the DVR may not operate properly and maintenance of the DVR may be difficult. Make sure that the air should be sufficiently circulated within the system operating room and the cover of the main system must be tightly fastened to prevent malfunction.

There are high voltage parts inside. Do not open the cover during operation.

The DVR must be installed in a place that meets the following environmental conditions.

- Operating temperature: 5°C ~ 40°C (41°F ~ 104°F)
- Operating humidity: 30% ~ 90% RH
- Input voltage: DC +12V 5A
- Power usage: About 25Watts
- Frequency: 60Hz/50Hz

Main replacement parts

- Hard disk (When HDD is factory-installed.): 1 year (25°C/77f environment)
- Cooling fan: 1 year (25°C/77f environment)
- Battery: 2 years (25°C/77f environment)

CAUTION

During the operation of this product, the fluctuation of input voltage must be within 10% of the rated voltage and the external power outlet must be grounded, otherwise, it may cause electric shock or malfunction of the product.

Do not connect heat-generating appliances to the same power outlet in which the product is plugged, otherwise it may cause a fire or malfunction of the product.

The use of an Automatic Voltage Regulator (AVR) is highly recommended to ensure that stable power is supplied.

CAUTION

The HDD that is installed in DVR can be replaced or upgraded by and authorized VITEK Repair Center. Warranty will be void if unit is opened by unauthorized personnel.

Components

The package contains the main unit and its components as specified below. When you purchase the package, please check to ensure the components specified below are included.

DVR	
Remote Controller	
Battery1.5V (AAA x 2EA)	
Adaptor and Power cable	
Client Software CD	
User Guide	

SPECIFICATIONS

ITEM				VT-H41 (4CH)	VT-H81 (8CH)	VT-H161 (16CH)
Video	Input	Channel, Input Level		4CH, Composite	8CH, Composite	16CH, Composite
		Signal Format		NTSC/PAL		
		Video Loss Check		Yes		
	Output	Main Monitor Output		1 CH BNC, 1CH VGA: Selectable		
		Signal Format		NTSC/PAL & VGA		
Audio	Input & Output			4 CH Line input & 1 CH Line output		
	Audio Codec			G.711(ADPCM)		
Alarm	Sensor Input ((NC/NO Selectable)			4	4	4
	Alarm Output			1 Alarm out by Alarm, Motion, Video Loss		
Record	Compression			H.264		
	Multi-operation			QUADPLEX (Playback/Record/Network/Backup)		
	Resolution	NTSC		352x240	352x240	352x240
					704x240	704x240
				704x480	704x480	704x480
		PAL		352x288	352x288	352x288
					704x288	704x288
				704x576	704x576	704x576
	Recording quality grade			NETWORK, ECONOMY, NORMAL, HIGH, FINE.		
	Recording Mode			Continuous / Schedule / Motion/ Sensor/ Manual		
	Motion Detection			Motion detection setup by Grid		
	Pre Recording			1 fps for 5 seconds before an event		
	Post Recording			10 seconds to 3 minutes after an event		
Display	Frame Rate (/Sec)			NTSC: 30fps/ch, 60 fields / PAL: 25fps/ch, 50 fields		
Playback	Multi-Decoding			1, 4	1, 4, 9	1, 4, 9, 16
	Playback Speed		Single channel	× 2, 4, 8		
			Multi-channels	× 2, 4		
	Search Mode			Timeline, Event, Archive, Log		
Storage	HDD		Interface Type	Serial ATA I		
			Capacity of 1 HDD	1TB		
			Internal HDD Number	1	1	1
	File system			NaFS		
	Backup		USB Flash drive	Video & Still Image		
			Network	Video & Still Image		
User I/F	Menu Display			Text UI		
	Input Method			Front buttons, Remote control		
	PTZ control & Keyboard DVR control			1 RS-485		

	Termination	Yes
Network	Dynamic DNS	Yes (Free DDNS)
	Network Interface	10/100 base-TX Ethernet (RJ-45)
Network Access	Client Software (1:1)	Live, Search, Backup, PTZF Camera Control
	Web viewer (1:1)	Live, Search, Backup, PTZF Camera Control
	Multi-sites Monitoring System (1:n)	Live, Search, Backup, PTZF Camera Control
Features	DLS (Day Light Saving)	Yes
	Internal Beep	By Alarm, Motion, Video Loss, HDD error
	Multi-Language	Yes
	S/W Upgrade	USB Flash drive
	Water - mark	Yes (Exclusive viewer)
Power source	Power	DC 12V 3A(for 4CH), DC 12V 5A(for 8,16CH)
Weight	Unit Weight (Gross weight)	1.6 Kgs (3.1 Lbs) / 3.5 Kgs (6.8 Lbs)
Dimension	Unit Dimension (W x H x D)	340 mm x 262 mm x 63 mm / 13.4" x 10.3" x 2.5"

INDEX

1. NAME & FUNCTION 10

1-1. Front panel 10

1-2. Remote controller 11

1-3. Rear panel and connection 12

2. SETTING UP THE DVR 15

2-1. Monitor Selection (TV monitor and VGA monitor) 15

2-2. Live screen 16

2-3. Time setting 17

2-4. DLS (Day Light Saving) time setting 19

3. OPERATION - RECORD 21

3-1. CONTINUOUS recording 21

3-2. MOTION DETECTION recording 22

3-3. SENSOR recording 24

3-4. Manual recording 26

3-5. SCHEDULE recording 26

4. OPERATION - PLAYBACK 29

4-1. EVENT SEARCH 29

4-2. TIMELINE SEARCH 31

4-3. GO TO SPECIFIC TIME 32

4-4. GO TO THE FIRST VIDEO 32

4-5. GO TO THE LAST VIDEO 32

4-6. SYSTEM LOG 33

4-7. ARCHIVE 33

5. OPERATION - BACKUP TO USB FLASH DRIVE 34

5-1. Archiving and backup JPEG in Live mode 35

5-2. Archiving and backup VIDEO in Playback mode 36

5-3. Backup JPEG, AVI, or EXCLUSIVE VIDEO from ARCHIVE search 38

5-4. Playback of AVI or EXCLUSIVE VIDEO 40

6. SETUP 41

6-1. LIVE 41

6-2. RECORD 43

6-3. DEVICE 45

6-4. NETWORK 47

6-5. STORAGE 51

6-6. SYSTEM 52

7. NETWORK ACCESS USING THE EXCLUSIVE NETWORK VIEWER 55

7-1. PC requirements 55

7-2. Installing the network viewer 55

7-3. Live monitoring mode and functions. 56

7-4. Bi directional audio 58

7-5. Remote search mode and functions 59

7-6. PC System configuration 62

8. NETWORK – BY A WEB-BROWSER VIEWER 66

APPENDIX: HOW TO CONNECT TO A NETWORK 68

A. How to set the IP address of the DVR and open the TCP port of the router? 68

B. How to access DVR from Remote PC? 70

1. NAME & FUNCTION

1-1. Front panel



① **SEQ:** To start auto sequencing of the screen in full screen mode. (Toggle)

② **PTZ:** To control PTZ operation

③ **SETUP:** To launch SETUP menu.

④ **CAPTURE:** To start operations of backup in live or playback mode.

⑤ **SEARCH:** To go to the search menu.

⑥ **REC:** To start and stop manual recording.

⑦ **PLAY/PAUSE:** To play or to pause the footage in playback mode.

⑧ **REW:** To rewind the footage at 1x, 2x, 4x, and 8x speed during playback.

⑨ **F/REW : During playback -** To move the playback position 60 seconds backward.

During pause - To move the playback position 1 frame backward.

⑩ **F/ADV: During playback -** To move the playback position 60 seconds forward.

During pause - To move the playback position moves 1 frame forward.

⑪ **FF:** To fast forward the footage at 1x, 2x, 4x, and 8x speeds during playback.

⑫ **USB port:** To connect USB Thumb drive to backup data.

⑬ **HDD:** The indicator blinks during recording and playback.

⑭ **POWER:** The indicator blinks when the AC adaptor is connected.

Direction button

During setting

ⓐ To move the cursor Upward. ⓑ To move the cursor to the Right or to change the setting values.

ⓒ To move the cursor Down. ⓓ To move the cursor to the Left or to change the setting values.

During Live/playback & Entering password

ⓐ To select camera 1 or To enter No. 1 ⓑ To select camera 2 or To enter No. 2.

ⓒ To select camera 3 or To enter No. 3. ⓓ To select camera 4 or To enter No. 4.

ⓔ To select full screen or quad screen view in live/playback or To select desired menu item or to store the setup value.ⓕ To return to previous menu screen or to exit from playback.

1-2. Remote controller



① **ID:** When a remote control ID number is set in DVR, press it before number.

② **REC:** To start and stop manual recording.

③ **Number:** To select channel (1, 2, 3, & 4) or to enter DVR ID number.

④ **F/REW: During playback -** To move the playback position 60 seconds backward.

During pause - To move the playback position 1 frame backward.

⑤ **F/ADV: During playback -** To move the playback position 60 seconds forward.

During pause - To move the playback position moves 1 frame forward.

⑥ **REW:** To rewind the footage at 1x, 2x, 4x, and 8x speed during playback.

⑦ **PLAY/PAUSE:** To play or to pause the footage in playback mode.

⑧ **FF:** To fast forward the footage at 1x, 2x, 4x, and 8x speeds during playback.

⑨ **Control button:** Press to move the menu items or select channel.

⑩ **SETUP:** To launch SETUP menu.

⑪ **SEARCH:** To go to the search menu.

⑫ **ESC: During setting -** To return to previous menu screen.

During playback - To exit from playback.

⑬ **BACKUP:** To start operations of backup in live or playback mode. (The same function button as CAPTURE on the front panel of DVR.)

⑭ **SEQ:** To start auto sequencing of the screen in full screen mode. (Toggle)

1-3. Rear panel and connection

1-3-1. Basic connections

- **Do not power this system on before all the connections are completed.**
- **Make sure all the connections are made properly. Faulty connection may result in the system being damaged.**
- **The DC plug of the AC adaptor is easy to be unplugged. Please make sure that the plug is**

VT-H41



VT-H81



VT-H161



Table 1.2 Rear Panel Connections

VIDEO IN	Four connectors for video input. Connect camera cable to Video-in (NTSC/PAL)
VIDEO OUT	Composite video output in NTSC or PAL format. Connect to Composite Monitor.
VGA	Connector for VGA monitor
RS-232	For engineering use only
SENSOR IN	Connector for sensor device. 4 sensors can be connected to the system. Sensor 1, 2, 3, 4 are dedicated to Video channel 1, 2, 3, 4, respectively. Either normally open (NO) or normally closed (NC) sensor can be selected. Simple On/Off switching. Connect two signal lines of sensor (infrared rays sensor, heat perception sensor, magnetic sensor) to the desired sensor number. (You can set the type-NC or NO- of sensor at "Setup" mode). **NOTICE** SENSOR inputs require dry contact only. Do not input any electric signal.
ALARM OUT	Connector for alarm device connection. Provides simple On/Off switching using relay. 0.5A/125V, 1A/30V
LAN	RJ45 connector for LAN connection
DC 12V	Apply 12V DC using the DC adaptor supplied with the equipment.
SWITCHES	Select VGA monitor or CVBS (Composite Video Blanking Sync) monitor. **Do not change the setting when the power is on.** **When the position of the switch is changed, the DVR should be rebooted to apply the new setting.**

1-3-2. Network connections

- **LAN Connection – Using the cross cable, without a switching hub**

  Connect to the system directly, using a cross type network cable



Cross type cable

- **LAN Connection – Using a switching hub**

  Connect to the system, using a hub (Switching hub) and an Ethernet cable (10BASE-T/100BASE-TX CAT 5 LAN cable)



IP Router or HUB

- **Internet (ADSL) Connection**

  Connect to the system, using a Router or ADSL modem and an Ethernet cable (10BASE-T/100BASE-TX CAT 5 LAN cable)



1-3-3. Sensor and alarm connections



SENSOR INPUT: Connect two signal lines of sensor (infrared ray sensor, heat perception sensor, magnetic sensor) to the desired sensor number.

NOTICE

SENSOR inputs need dry contact only. Do not input any electric signal.

---: Not operational

N/O: Normally open type sensor. When magnetic sensor is closed, sensor sends a signal.



N/C: Normally closed type sensor. When magnetic sensor is opened, sensor sends a signal.



ALARM OUTPUT: Use Maximum current: 0.5A/125VAC, Maximum voltage: 1A/30VDC. When controlling lamp and AC operated equipment, control it using separate outside relay. During normal operation the control output contact is maintained at “Open” status, and during control output the output contact is changed to Closed(short)” status.

2. Setting up the DVR

2-1. Monitor Selection (TV monitor and VGA monitor)

2-1-1. CVBS: Select CVBS to connect general TV monitor



2-1-2. VGA: Select VGA to connect computer VGA monitor



- **The general TV monitor terminal and the computer VGA monitor terminal can not be used**

2-2. Live screen

While the system is booting, “INITIALIZING” message is displayed. After the system booting is finished, the video inputs from the cameras are displayed.

Various indicators showing the status of the DVR are shown as OSD symbols. These OSD and video display can be hidden.



Indicator	Description
C	Continuous recording in progress
R	Manual recording in progress
S	Sensor alarm recording in progress
M	Motion alarm recording in progress
	Indicates that audio/audios is/are mute, single, or mixed.
	Indicates that alarm is detected
	Indicates that motion is detected
	Indicates that a network client is connected to the DVR.
	Indicates that sequencing mode is enabled.
R:A,0..	Indicates that remote controller ID is set.
	Indicates the HDD is being recycled

- **If camera is not connected or the connector is not properly connected to video input terminal, "NO VIDEO" is displayed on the monitor.**

2-3. Time setting

1. Press the SETUP button. Press Up arrow button four times to enter "1111" (Default password) and press the SEL button. Then the SETUP screen is displayed. The password change is highly recommended to avoid any unauthorized usage.



2. Press the direction button to select the SYSTEM menu and press the SEL button.



3. Go to DATE FORMAT field using button and select the date format using ▶◀ button.
   - YYYY/MM/DD (Ex. 2008/5/6)
   - MM/DD/YYYY
   - YYYY-MM-DD (Ex. 2008-05-06)
   - MM-DD-YYYY
   - DD-MM-YYYY
4. Go to DATE & TIME field using button and press the SEL button.
5. Select the date and time that is to be changed using ▶◀ button, change a value using button, and press the SEL button. Then UPDATE DATE & TIME screen is displayed.





6. Select CONFIRM and press the SEL button. Then the system will reboot automatically showing "INITIALIZING..." message.

Setting in TIME MISMATCH

When the time of DVR is set earlier than the time of the last video data on HDD, the following message is displayed.


TIME MISMATCH.202
WILL YOU ERASE INDEX?
IF YES, SOME DATA WILL BE ERASED FROM HDD.
IF THE DATA IS TO BE KEPT, SELECT GO TEST MODE.
SYSTEM TIME: Fri Oct 24 14:59:59 2008
HDD FIRST TIME: Fri Oct 24 14:59:30 2008
GO TEST MODE YES

- Selecting "YES": the video data between "SYSTEM TIME" and "HDD LAST TIME" will be

deleted.

- Selecting “GO TO TEST MODE”: Selects only the video data between “SYSTEM TIME” and “HDD LAST TIME” and will not be deleted. Otherwise, do not select “GO TO TEST MODE”.

2-4. DLS (Day Light Saving) time setting

- EU Territory – When your time zone belongs to EU territory
  1. Go to SYSTEM>DLS field using button and select EU using ▶◀ button.
  2. Go to GMT AREA field using button and select GMT time of your country from +00:00 to +05:00.



- USA Territory – When your time zone belongs to USA territory
  1. Go to SYSTEM>DLS field using button and select USA using ▶◀ button.



- Other Territory – When your time zone does not belong to USA and EU territory
  1. Go to SYSTEM>DLS field using button and select ETC using ▶◀ button. Then the summer time setup fields are displayed.



2. Select BEGIN field using button and press the SEL button. Then DAYLIGHT SAVING BEGIN screen is displayed.
3. Select the date and time that is changed using ▶◀ button, change a value using button, and press the SEL button.

4. After exit from DAYLIGHT SAVING BEGIN field setting, select DAYLIGHT SAVING END field using button and press the SEL button. Then DLS BEGIN screen is displayed.
5. Select the date and time that is changed using ▶◀ button, change a value using button, and press the SEL button.

3. OPERATION - RECORD

The system has 6 recoding modes.

- CONTINUOUS recording – Recording continuously when the DVR is turned on.
  C icon is displayed on the screen. (Refer to page 25)
- MOTION DETECTION recording – Recording when the DVR detects motion form input video.
  M icon is displayed on the screen. (Refer to page 25)
- SENSOR recording – Recording when the external sensor of DVR is set off.
  S icon is displayed on the screen. (Refer to page 28)
- SCHEDULE recording – Recording according to the schedule setting. (Refer to page 30)
- None – No recording
- Manual recording by REC button – Recording when the REC button of DVR is pressed.
  R icon is displayed on the screen. (Refer to page 29)





3-1. CONTINUOUS recording

CONTINUOUS recoding setting is available for each channel. The DVR records automatically input video in CONTINUOUS recording mode as a factory default, unless RECORDING mode is changed.

① Set the basic record menu using ▶◀ buttons before setting Motion detection.

- RESOLUTION
- CHANNEL
- FRAME RATE
- QUALITY

Upon connecting cameras, the DVR records input video displaying C on the screen.

② To stop CONTINUOUS recording, go to RECORDING BY filed using button and select NONE using ▶◀button.



③ Repeat this step to set the other channel as necessary.

④ Press ESC button to go to SAVE SETUP and save the

.

3-2. MOTION DETECTION recording

A motion detection setting is available for each channel.

① Set the basic record menu using the direction buttons before setting Motion detection.

- RESOLUTION
- CHANNEL:
- FRAME RATE
- QUALITY

Upon Motion detection, the DVR records input video with these setting.

② To select a channel for motion detection recording, go to CHANNEL filed using button and select a channel from CH1, CH2, CH3, and CH4 using ▶◀ button.

③ Go to RECORDING BY filed using button and select MOTION using ▶◀button.



④ Go to DEVICE>CHANNEL>MOTION ZONE filed using button and select PARTIAL ZONE using ▶◀button.





When FULL ZONE is selected, the DVR detects motion from the entire video screen. Set only MOTION SENSITIVITY.

⑤ Select the grids for motion detection using ▶◀button and SEL button. Then the selected grids are displayed in Pink color.

⑥ Go to MOTION SENSITIVITY using button and select the sensitivity using ▶◀button.



Sensitivity grade: 9 –The highest sensitivity against motion / 1 – The lowest sensitivity against

⑦ Go to PRE RECORD using button and select ON or OFF as necessary using ▶◀button.

When PRE RECORD is ON, the DVR records 1 fps for 5 seconds before any motion detection.



⑧ Go to POST RECORD using button and select the time as necessary using ▶◀button.



The available POST RECORD time: 5 to 60 seconds.

⑨ Repeat this step to set the other channel as necessary.

⑩Press ESC button to go to SAVE SETUP and save the setting

3-3. SENSOR recording

Sensor is connected to each channel and be used a recording trigger.

① Connect a sensor to a sensor terminal on the rear of the DVR. (Refer to page 18)

② Set the basic record menu using ▶◀ buttons before setting Sensor recording.

- RESOLUTION
- CHANNEL
- FRAME RATE
- QUALITY

When sensor sends a signal to the DVR, the DVR records input video displaying S on the screen.

③ To select a channel for sensor triggered recording, go to CHANNEL field using button and select a channel from CH1, CH2, CH3, and CH4 using ▶◀ button.

④ Go to RECORDING BY field using button and select SENSOR using ▶◀button.



⑤ Go to DEVICE>CHANNEL>SENSOR RECORDING using button and select the number of sensors that are linked with the video channel using ▶◀button.



⑥ Go to PRE RECORD using button and select ON or OFF as necessary using ▶◀button.

⑦ Go to POST RECORD using button and select the time as necessary using ▶◀button.

Repeat this step to set the other channels as necessary.
Press ESC button to go to SAVE SETUP and save the setting.

Alarm setting on activation of event such as motion, sensor, video loss, & HDD fail

When an event is activated, a relay signal triggers the external alarm device.

ⓐ Connect an external alarm device to the alarm out terminal (Refer to page 18)

ⓑ Go to DEVICE>ALARM field using button and select OFF, SENSOR, MOTION, VIDEO LOSS, HDD FAIL, or ALL as necessary using Enter button.



ⓒ Go to ALARM/BEEP DURATION using button and select alarm/beep duration as necessary using Enter button.



ⓓ Press ESC button to go to SAVE SETUP and save the setting.

3-4. Manual recording

To start manual recording, press REC button. Then, “R” is displayed on the screen and the DVR starts recording all channels.

To stop manual recording, press REC button. Then, “R” disappears on the screen and the DVR stops recording all channels.

3-5. SCHEDULE recording

① Set the basic record menu using ▶◀ buttons before setting Schedule.

- RESOLUTION
- CHANNEL
- FRAME RATE
- QUALITY

Upon connecting cameras, the DVR records input video using schedule setting.

② Before setting the schedule, set the following as necessary

- MOTION ZONE
- MOTION SENSITIVITY
- SENSOR TYPE
- PRE RECORD
- POST EVENT RECORD

③ Go to RECORDING BY field using button and select SCHEDULE using ▶◀button.

Go to SCHEDULE using button and press SEL button. Then SCHEDULE setting screen is displayed. (When the channel 1 is selected from CHANNEL field, "SCHEDULE – CH1" is displayed.)



Move the cursor to one of following fields and set a different mode using SEL button.



ⓐ: Same recording mode setting applies to every day.

ⓑ: Same recording mode setting applies to the whole day.

ⓒ: Same recording mode setting applies to a specified time of every day.

ⓓ: Recording mode setting applies to a specified time of the day.

Repeat the procedure to select a recording mode using SEL button from;

C: CONTINOUS recording M: MOTION DETECTION recording

S: SENSOR recording - : DISABLE (No recording)

EXAMPLE of SCHEDULE recording setting

ⓐ: CONTINOUS recording mode applies to every day.



ⓑ: MOTION DETECTION recording mode setting applies to the whole day.



ⓒ: SENSOR recording mode setting applies to a specified time of every day.



EXAMPLE of copying the CH1 SCHEDULE recording setting to CH2

(1) Set the CH1 SCHEDULE and return RECORD menu using ESC button.



(2) Go to CHANNEL field and select CH2 using ▶◀ buttons. And go to SCHEDULE field and press SEL button. Then SCHEDULE – CH2 screen is displayed.

(3) Move the cursor to COPY FROM using buttons and select CH1 using ▶◀ buttons. Finally

press SEL button. Then the CH1 SCHEDULE recording setting is copied to CH2.



4. OPERATION - PLAYBACK

The system has 7 methods of searching a recorded video.



- EVENT SEARCH – Searching through the calendar, channel, and recording mode. (Refer to page 33)
- TIMELINE SEARCH – Searching through the calendar and the timeline. (Refer to page 34)
- GO TO SPECIFIC TIME – Searching through selected date and time. (Refer to page 35)
- GO TO THE FIRST VIDEO – Searching the oldest recorded video. (Refer to page 36)
- GO TO THE LAST VIDEO – Searching the last recorded video. (Refer to page 36)
- SYSTEM LOG – View the system log data. (Refer to page 36)
- ARCHIVE – Searching the archived JPEG or video data through the calendar. (Refer to page 37)

4-1. EVENT SEARCH

① Press SEARCH button. Then SEARCH menu is displayed.



② Go to EVENT SEARCH and press SEL button. Then SEARCH screen is displayed.



③ Select the date, a channel, and the type of recording mode using ▶◀ buttons and SEL button.

A: Showing all the recorded data list of every type of recording mode

M: Showing the recorded data list by motion detection. (BY MOTION)

S: Showing the recorded data list by sensor detection. (BY SENSOR)

R: Showing the recorded data list by manual recording.

C: Showing the recorded data list by continuous record. (BY CONTINOUS)

Select one of the recording data list using buttons and SEL button. To change pages of the recorded data list, use ▶◀ buttons. Then, playback starts.





4-2. TIMELINE SEARCH

① Press SEARCH button. Then SEARCH menu is displayed.

② Go to TIMELINE SEARCH and press SEL button. Then SEARCH calendar screen is displayed.



③ Select the date using ▶◀ buttons and SEL button. Then Timeline screen is displayed.



Move the vertical Yellow line to the time between 0 to 24 HOUR using ▶◀buttons and SEL button.



Move the vertical Yellow line to the time between 0 to 60 MIN using ▶◀buttons and SEL button. Then, playback starts.



4-3. GO TO SPECIFIC TIME

① Press SEARCH button. Then SEARCH menu is displayed.

② Go to GO TO SPECIFIC TIME and press SEL button. Then SEARCH screen is displayed.



③ Select the date and time using ▶◀ buttons and press SEL button.

Then, playback starts. When there is no recorded data, the closest data to the selected time is played back.

4-4. GO TO THE FIRST VIDEO

① Press SEARCH button. Then SEARCH menu is displayed.

② Go to GO TO THE FIRST VIDEO and press SEL button. Then, playback of the oldest recorded video data starts.

4-5. GO TO THE LAST VIDEO

① Press SEARCH button. Then SEARCH menu is displayed.

② Go to GO TO THE LAST VIDEO and press SEL button. Then, playback of the last recorded video data starts.

4-6. SYSTEM LOG

① Press SEARCH button. Then SEARCH menu is displayed.

② Go to SYSTEM LOG and press SEL button. Then SYSTEM LOG calendar screen is displayed.



③ Select the date using ▶◀ buttons and press SEL button. To change pages of the log data list, use ▶◀ buttons. Then, log list screen of the date is displayed.



4-7. ARCHIVE

The archived still-images or video in Live screen or Playback screen can be searched and played back.

① Press SEARCH button. Then SEARCH menu is displayed.

② Go to ARCHIVE and press SEL button. Then ARCHIVE calendar screen is displayed.



③ Select the date using ▶◀ buttons and press SEL button. Then ARCHIVE LIST screen is displayed.



Select one of the archived data listed using buttons and press SEL button. To change pages of the archived data list, use ▶◀ buttons. Then, the archived still-image or the first frame of video data is displayed.

5. OPERATION - BACKUP TO USB FLASH DRIVE

JPEG and video can be backed up to USB flash drive.



When USB flash drive cannot be recognized, format USB flash drive as FAT format

- Archiving and backup JPEG in Live mode – JPEG image can be archived on HDD and be backed up to USB flash drive in live mode. (Refer to page 39)
- Archiving and backup VIDEO in Playback mode – JPEG, AVI, or EXCLUSIVE VIDEO can be archived on HDD and be backed up to USB flash drive in playback mode. (Refer to page 40)
- Backup JPEG, AVI, or EXCLUSIVE VIDEO from ARCHIVE search – JPEG, AVI, or EXCLUSIVE VIDEO can be backed up from ARCHIVE search menu. (Refer to page 41)
- Playback of AVI or EXCLUSIVE VIDEO – AVI can be played back using Media Player software. EXCLUSIVE VIDEO can be played back using the exclusive viewer. (Refer to page 43)

When the selected list is video, VIDEO TYPE screen is displayed.

- AVI: When AVI is selected, the video is backed up as AVI format.
- EXCLUSIVE VIDEO: When this is selected, the video is backed up as an exclusive video format that can be played back using the exclusive viewer.

5-1. Archiving and backup JPEG in Live mode

① Connect a USB flash drive to the USB terminal.

② Press CAPTURE button at the scene to be backed up. “JPEG IMAGE IS ARCHIVED ON HDD” is displayed.



③ Then SAVING screen with backup status bar is displayed after “CHECKING USB” message.



After the backup is done, “BACKUP IS COMPLETED” message is displayed.



⑤ When the DVR can not recognize USB thumb drive or no USB thumb drive is connected to the USB terminal, “PLEASE CHECK BACKUP DEVICE” message is displayed.

5-2. Archiving and backup VIDEO in Playback mode

① Connect a USB flash drive to the USB terminal.

② Press SEARCH button and go to the video to be backed up.



③ Press CAPTURE button at the scene of video to be backed up. Then SELECT BACKUP FILE TYPE screen is displayed. Select a file type from JPEG, AVI, or EXCLUSIVE VIDEO using ▶◀ buttons and press SEL button. Then DURATION screen is displayed.



When JPEG IMAGE is selected, please use the same backup procedure as 5-1. ③

⑤ Set the duration to be archived and backed up from the scene of video using buttons and press SEL button.





⑥ Then SAVING screen with backup status bar is displayed



⑦ After the backup is done, “BACKUP IS COMPLETED” message is displayed.



5-3. Backup JPEG, AVI, or EXCLUSIVE VIDEO from ARCHIVE search

① Press SEARCH button. Then SEARCH screen is displayed.



② Go to ARCHIVE field using buttons and press SEL button. ARCHIVE search calendar is displayed. Select the date in Red using ▶◀ buttons and SEL button. LIST screen is displayed.

③ Select VIDEO clip from the list using buttons and SEL button. Then a paused image or the first scene of the video is displayed.



④ Press CAPTURE button.

⑤ Select AVI or EXCLUSIVE VIDEO using ▶◀ buttons and press SEL button.

⑥ Select USB FLASH DRIVE using ▶◀ buttons and press SEL button. SAVING screen with backup status bar is displayed.



⑦ After the backup is done, “BACKUP IS COMPLETED” message is displayed.



5-4. Playback of AVI or EXCLUSIVE VIDEO

- Playback of AVI format: AVI format video can be played back by Windows Media Player™ or other media player that is compatible with AVI format video.

  When PC doesn’t have proper H.264 CODEC, the media players can not playback the AVI format video. In this case, you may install CODEC that is provided on the

- DVR (Exclusive video format): DVR format video can be played back by the player (the exclusive viewer) that the DVR copies on USB thumb drive with video.

  Three files are copied on USB thumb drive

  - DVR file: Exclusive format video file.
  - SMI file: Title file of date and time.
  - PLAYER: Exclusive video viewer.





6. SETUP

Press the SETUP button, then the password window is displayed. The default password is 1111, which can be entered by pressing the up button 4 times and then pressing the SEL button. After input password, the SETUP screen is displayed.



6-1. LIVE



Item	Description
OSD	Enable/disable OSD (on-screen-display).
SEQUENCE	Enable/disable sequential display of video channels in full screen

	mode.
SEQ-DWELL TIME	Dwell time for each cannel display in sequential display mode.
OSD CONTRAST	Set the visibility level of the On Screen Display (OSD)
CHANNEL	Select the channel for applying the following settings.
DISPLAY	Enable/disable display of the video channel in live display mode
SEQUENCE LIST	Enable/disable the specified channel to be included in sequential list.
BRIGHTNESS	Change the brightness value for the specified channel
CONTRAST	Change the contrast value for the specified channel
HUE	Change the hue value for the specified channel
SATURATION	Change the saturation value for the specified channel

OSD – Select ON/OFF using ▶◀ buttons.

ON: OSD (on-screen-display) such as the time, date, the channel, and the characters and symbols are displayed on the screen.

OFF: OSD (on-screen-display) is NOT displayed, except recording indicator icons.

SEQUENCE – Select ON/OFF using ▶◀ buttons.

ON: Channel in full screen mode is rotated.

OFF: Channel on a single live screen is NOT rotated.

SEQ-DWELL TIME – Select channel sequence interval time using ▶◀ buttons.

Setting values: 1, 2, 3, 4, ~ 56, 57, 58, 60 seconds.

OSD CONTRAST – Set the contrast of OSD on the screen using ▶◀ buttons.

Setting values of the display bar: 20% (the most transparent) ~ 100%

Renaming of CHANNEL

① Select CHANNEL using ▶◀ buttons and press SEL button. Then the CAMERA TITLE screen is displayed.



② Input characters using ▶◀ buttons.

Available characters list:

A B C D E F G H I J K L M N O P Q R S T U V W X Y Z

[＼] ^ _ ‘ a b c d e f g h i j k l m n o p q r s t u v w x y z

{ | } ! “ # $ % & ’ ( ) * + , - . / 0 1 2 3 4 5 6 7 8 9 : ; < > ? @

Setting of CHANNEL - Select CHANNEL to set the video setting as bellows using ▶◀ buttons

DISPLAY – Select ON/OFF using ▶◀ buttons.

ON: The live screen of the channel is displayed.

OFF: The live screen of the channel is NOT displayed.

SEQUENCE LIST – Select ON/OFF using ▶◀ buttons.

ON: The channel is included in sequencing channels.

OFF: The channel is NOT included in sequence list.

BRIGHTNESS – Set the brightness of the channel using ▶◀ buttons.

Setting values of the display bar: 0% ~ 100% (The most brightness)

CONTRAST – Set the contrast of the channel using ▶◀ buttons.

Setting values of the display bar: 0% ~ 100% (The most contrast)

HUE – Set the hue of the channel using ▶◀ buttons.

Setting values of the display bar: 0% ~ 100%

SATURATION – Set the saturation of the channel using ▶◀ buttons.

Setting values of the display bar: 0% ~ 100%

6-2. RECORD



Menu item	Description
RESOLUTION	Set resolution to either 704x480(NTSC)/704X576(PAL) or 352x240(NTSC)/352X288(PAL).
CHANNEL	Select the channel for applying the following settings.
FRAME RATE	Set the frame rate for the specified channel. The sum of the frame rate values from each channel cannot exceed maximum frame rates for a particular recording resolution. **The maximum frame rate: 120/100fps - 352x240(NTSC)/352X288(PAL)** **30/25 fps - 704x480(NTSC)/704X576(PAL)**
QUALITY	Select the recording quality for the specified channel from NETWORK, ECONOMY, NORMAL, HIGH, FINE.
RECORDING BY	Assign the recording mode for each channel. Recording modes: CONTINOUS, MOTION, SENSOR, SCHEDULE, and NONE.
PRE RECORD	Enable/disable pre-event recording. Pre-event recording time is 5 sec and only intra-frames are recorded for pre-event recording.
POST RECORD	Set post event recording time duration for the specified channel
AUDIO	Enable/disable audio for the specified channel
SCHEDULE	Set recording schedule.

RESOLUTION – Select the resolution for the recording using ▶◀ buttons.

352x240: The input video is recorded as 352x240 resolution.

704x240: The input video is recorded as 704x240 resolution.

704x480: The input video is recorded as 704x480 resolution.

The resolution setting is applied to every channel.

Setting of CHANNEL - Select CHANNEL to set the recording setting as below using ▶◀ buttons

FRAME RATE – Set the frame rate value using ▶◀ buttons.

The total frame rate when resolution is 704X480(NTSC) / 704X576(PAL): 30 / 25

The total frame rate when resolution is 352X240 (NTSC) / 352X288(PAL): 120 / 100

QUALITY – Select the quality of the recording video using ▶◀ buttons.

Setting values: FINE, HIGH, NORMAL, ECONOMY, NETWORK (default : HIGH)

RECORDING BY – Select the recording mode using ▶◀ buttons.

CONTINOUS: The input video is recorded when the DVR is turned ON.

MOTION: The input video is recorded when the motion is detected.

SENSOR: The input video is recorded when the external sensor is activated.

SCHEDULE: The input video is recorded according to SCHEDULE setting.

NONE: The input video is NOT recorded.

PRE RECORD – Select ON/OFF of the pre-recording on the event using ▶◀ buttons.

ON: 1ips of video for 5 seconds is recorded before the event (motion detection or sensor activation).

OFF: No pre-recording.

POST RECORD – Set the recording time after the event using ▶◀ buttons.

Setting values: 5 ~ 30 seconds

AUDIO – Select ON/OFF of the audio recording using ▶◀ buttons.

ON: The audio is recorded.

OFF: The audio is NOT recorded.

SCHEDULE – Set the recoding schedule of each channel.

6-3. DEVICE



Item	Description
CHANNEL	Select the channel for applying the following settings.
MOTION ZONE	Select Full Zone or Partial Zone for motion sensing.
MOTION SENSITIVITY	Set the motion sensitivity for the specified channel.
SENSOR RECORDING	Select the channel to link with sensor.
SENSOR	Select the sensor for applying the following settings.
TYPE	Set the type of sensor for the specified channel from none, NORMAL OPEN & NORMAL CLOSE
ALARM	Select from OFF, SENSOR, MOTION, VIDEO LOSS, HDD FAIL, & ALL..
BEEP	Select from OFF, SENSOR, MOTION, VIDEO LOSS, HDD FAIL, & ALL...
ALARM/BEEP DURATION	Set alarm and beep duration
PTZ	PTZ control setting
REMOTE CONTROLLER ID	Select the ID of remote controller.
BUTTON TONE	Enable / Disable the sound tone of front buttons.

CHANNEL - Select CHANNEL to set the recording setting as bellows using ▶◀ buttons

MOTION ZONE – Select the motion zone type using ▶◀ buttons.

FULL ZONE: The motion on the whole screen is detected.

PARTIAL ZONE: The motion on the pre-set detection grid is detected.

MOTION SENSITIVITY – Set the level of motion detection sensitivity using ▶◀ buttons.

SENSOR RECORDING – Select the sensor to link with the recording channel using ▶◀ buttons.

SENSOR - Select a sensor to set the type using ▶◀ buttons

TYPE – Select the external sensor type using ▶◀ buttons.

---: No operation NORMAL OPEN: Normally open type sensor NORMAL CLOSE: Normally closed type sensor

ALARM - Select an event to link with alarm using ▶◀ buttons.

OFF: An event signal is NOT linked with the external alarm.

SENSOR: A sensor event signal is linked with the external alarm.

MOTION: An event signal of motion is linked with the external alarm.

VIDEO LOSS: An event signal of video loss is linked with the external alarm.

HDD FAIL: An event signal of HDD failure is linked with the external alarm.

ALL: Every event signal is linked with the external alarm.

BEEP - Select an event to link with beep using ▶◀ buttons.

OFF: An event signal is NOT linked with the internal beep.

SENSOR: A sensor event signal is linked with the internal beep.

MOTION: An event signal of motion is linked with the internal beep.

VIDEO LOSS: An event signal of video loss is linked with the internal beep.

HDD FAIL: An event signal of HDD failure is linked with the internal beep.

ALL: Every event signal is linked with the internal beep.

ALARM/BEEP DURATION - Select the length of alarm and beep output using ▶◀ buttons.

Setting values: 5 / 6 / 7 ~ 57 / 58 / 59 / 60 seconds

PTZ - PTZ control setting

① Connect the RS-485 cables of PTZ camera to the RS-485 port on the rear panel.



RS-485: D+

RS-485: D-

② Press SEL button to enter the menu. Then PTZ menu screen is displayed. Select the Specific CAMERA CHANNEL, CAMERA TYPE, CAMERA SPEED, and ID.



③ Press the PTZ button on the front panel. The control screen will appear. Highlight the item to select and control the cameras by using the UP and DOWN or LEFT and RIGHT buttons.

Item	Description
PAN / TILT	Use the UP or DOWN button for TILT and LEFT or RIGHT button for PAN of the selected camera.
ZOOM /	Use the UP or DOWN button for ZOOM in or out and LEFT or

FOCUS	RIGHT button for FOCUS near or far of the selected camera.
INITIALIZE	Initialize the PTZ settings of the selected camera.

REMOTE CONTROLLER ID (Example: Number 3)

① Select REMOTE CONTROLLER ID using buttons and select the ID number from 3 using ▶◀ buttons. And exit from the setup menu.

② Press the ID button on the remote controller and press the number 3 button. Then icon is displayed on the screen.

BUTTON TONE - Enable / Disable the sound tone of front buttons using ▶◀ buttons.

6-4. NETWORK



Item	Description
PORT	Individual port for network streaming when connecting the DVR to a multiple unit network. (Default: 5445)
WEB PORT	Port for Web Viewer, default : 80
CLIENT ACCESS	Enable/Disable remote access through client software.
BANDWIDTH SAVING	Enable/Disable only key frame transmission when the network bandwidth is not enough.
NETWORK TYPE	Set the type of network connection. Options are: LAN, DHCP, ADSL Default : DHCP
DDNS	Enable/disable using domain name address through DDNS server.
SEND E-MAIL	Send an e-mail notification with captured image when event happens.

PORT

① Select PORT using buttons and press SEL button. Then the SET PORT screen is displayed.

② Input a port number using ▶◀ buttons and press SEL button.

When you connect one or more DVRs to a network through an IP sharing device, each device must have a unique TCP port number for access to each unit from outside the LAN. Also, the IP sharing device must be configured for port forwarding so when each port is accessed on the IP sharing device, it will forward to the

Network access beyond Router
In order to access beyond Router (Firewall), user must open 1 TCP port for Command, Live steaming, and Search streaming. If this port is not open properly, user can not access DVR beyond a router.

WEB PORT - Input a web port number using buttons.



CLIENT ACCESS – Select ON/OFF using ▶◀ buttons.

ON: Remote access through client software is allowed.

OFF: Remote access through client software is NOT allowed.

BANDWIDTH SAVING – Select ON/OFF using ▶◀ buttons.

ON: Only a key frame is transmitted (Favorable for use of low network bandwidth).

OFF: Every frame is transmitted. Mostly, set "OFF" for normal use.

Setting of NETWORK TYPE - Select NETWORK TYPE using ▶◀ buttons.

DHCP – DVR automatically obtains IP varying from time to time from network.

An IP address is automatically assigned by the DHCP server, which automatically assigns an IP address and other parameters to new devices. When ADSL or other network being used adopts variable IP method, not fixed IP. This option is used as a way to automatically

ADSL

① Select ID using buttons and press SEL button.

② Input the registered ID that is necessary for ADSL connection using ▶◀ buttons and press SEL button.



③ Select PASSWORD using buttons and press SEL button.

④ Input the registered PASSWORD that is necessary for ADSL connection using ▶◀ buttons and press SEL button.

⑤ Press ESC button. Then the APPLY NETWORK ADDRESS screen is displayed.



⑥ Select CONFIRM using ▶◀ buttons and press SEL button. Then the DVR reboots automatically.

Use this ADSL (PPPoE) function when the network type connected to the DVR is PPPoE method. If ADSL type is not using inputting IP and Password like VDSL or DVR is installed in IP sharer, a user can not select this function. In this case, a user should select DHCP or

LAN

① Select IP ADDRESS using buttons and press SEL button. The IP ADDRESS input screen is displayed.

② Input the IP address that is assigned for the DVR using ▶◀ buttons and press SEL button.



③ Repeat ② for the GATEWAY, SUBNETMASK, and DNS as necessary.



④ Press ESC button. Then the APPLY NETWORK ADDRESS screen is displayed.

⑤ Select CONFIRM using ▶◀ buttons and press SEL button. Then the DVR will reboot automatically.

1. Regarding the use of fixed IP, please ask your network administrator if you do not have this information.
2. When DVR is installed in IP sharer that is connected with ADSL, a user can assign fixed IP to DVR from IP sharer itself using "DMZ" function out of such

Setting of DDNS – Select ON/OFF using ▶◀ buttons.

ON: The network access by the pre-registered domain name address that is pre-registered on www.vitekddns1.com is allowed. DDNS SERVER NAME appears.

OFF: The network access by the pre-registered domain name address that is pre-registered on www.vitekddns1.com is NOT allowed.

CAUTION: Do not change this sever name, ddnscenter.com. If this is changed, the DDNS service cannot be used.

Send E-mail – Using ▶◀ buttons, select ON. Then the SEND E-MAIL screen is displayed.

Using buttons, set up mail information



IP NOTIFICATION: Enable/disable sending information on IP address of DVR when it is changed

EVENT ALARM: Enable/disable sending e-mail reports when event alarm occurred.

MAIL TO: Enter the appropriate email address to enable sending daily e-mail reports.

MAIL SERVER NAME: Enter the appropriate email server information to enable sending daily e-mail reports.

USER: Enter the ID of email address.

PASSWORD: Enter the password of email address.

RETURN MAIL ADDRESS: Enter the e-mail address for return email. When e-mail does not deliver or not work properly, the return email will be delivered to this e-mail address.

6-5. STORAGE



Item	Description
OVERWRITE	Enable/Disable Overwrite existing old video data when hard disk drive is full
HDD FORMAT	Format hard disk drive
DISK INFORMATION	Shows the HDD information
RECORD LIMIT	Set the limit days for recording to the hard disk drive from 1 to 60 days

OVERWRITE – Select ON/OFF using ▶◀ buttons.

ON: When the HDD is fully recorded, former video data is deleted to record the new video data.

OFF: When the HDD is fully recorded, the recording stops.

HDD FORMAT

① Select FORMAT using ▶◀ buttons and press SEL button. Then the FORMAT screen is displayed.

② Select CONFIRM using ▶◀ buttons and press SEL button. Then the "FORMATTING" message is displayed and HDD formatting starts.

③ After HDD formatting is completed, the DVR reboots automatically.

DISK INFORMATION – Shows the HDD information.

RECORD LIMIT – Select the maximum days of recording using ▶◀ buttons.

Setting values: 1 / 2 / 3 / 4 ~ 57 / 58 / 59 / 60 days.

6-6. SYSTEM



DESCRIPTION	Press SEL to see system information.
DATE FORMAT	Select the preferred date and time display.
SET DATE & TIME	Set the present date and time. If DLS function is ON, user can not enter into this menu and change data and time.
DLS	Set DLS (Daylight Saving).
ADMIN PASSWORD	Set the password for the administrator. The default password is 1111.
NETWORK PASSWORD	Set the password of network client. The default password is 1111.
LANGUAGE	Select a language.
LOAD DEFAULT	Choose OFF or ON. If selecting ON, press the SEL button to load defaults.
LOAD FACTORY DEFAULT	Select ON to reset the system to the factory default settings.
SAVE SETUP TO A USB	User can save the current menu setting value to the USB memory stick.
LOAD SETUP FROM A USB	User can upload the menu setting value of DVR to another DVR using the USB Memory stick.
USB UPGRADE	The firmware of DVR can be upgraded through USB port

DESCRIPTION – Select DESCRIPTION using buttons and press SEL button.

MAIN BOARD VERSION: Displays the version of the system main board.

FIRMWARE VERSION: Displays the version of the system firmware.

STORAGE SIZE: Displays the capacity of the HDD.

IP ADDRESS: Displays the IP address of the DVR.

MAC ADDRESS: Displays the MAC address of the DVR.

DATE FORMAT – Refer to "2-3. Time setting"

SET DATE & TIME – Refer to "2-3. Time setting"

DLS – Refer to "2-4. DLS (Day Light Saving) time setting".

ADMIN PASSWORD – Select ADMIN PASSWORD using buttons and press SEL button. Then the ADMIN PASSWORD screen is displayed.

NETWORK PASSWORD – Select NETWORK PASSWORD using buttons and press SEL button. Then the NETWORK PASSWORD screen is displayed.

Changing of PASSWORD (ADMIN/NETWORK)

① Select ADMIN PASSWORD / NETWORK PASSWORD using buttons and press SEL button.

Then the Current password input screen is displayed.

② Enter the current password using (1) ▶ (2) (3)◀(4) buttons and press SEL button. Then the New password input screen is displayed.

③ Enter the new password using (1) ▶(2) (3)◀(4) buttons and press SEL button. Then the confirm password input screen is displayed.

④ Enter the same password as the new password using (1) ▶(2) (3)◀(4) buttons and press SEL button. Then the "PASSWORD CHANGED" message is displayed.

LANGUAGE – Select LANGUAGE using buttons and Select a language using ▸◂ buttons.

LOAD DEFAULT – Select LOAD DEFAULT to initialize the setting using buttons and press SEL button, Select confirm. Then LOAD DEFAULT screen is displayed.

The DVR is rebooted automatically when LOAD DEFAULT is confirmed

LOAD FACTORY DEFAULT – Select LOAD FACTORY DEFAULT to initialize the setting using buttons and press SEL button. Select confirm.

NOTE Every setting value of the DVR will be initialized as factory-setting value.

SAVE SETUP TO A USB

① Connect USB thumb drive to the USB port.

② Select SAVE SETUP TO A USB using buttons and press SEL button. Then the CONFIRMATION screen is displayed.

③ Select CONFIRM using ▸◂ buttons and press SEL button. Then the saving the menu setting value starts automatically.

④ After saving is completed, the SYSTEM menu screen is displayed.

LOAD SETUP FROM A USB

① Connect USB thumb drive that has a menu setting value to the USB port.

② Select LOAD SETUP FROM A USB using buttons and press SEL button. Then the CONFIRMATION screen is displayed.

③ Select CONFIRM using ▸◂ buttons and press SEL button. Then the uploading the

menu setting value starts automatically..

④ After uploading is completed, then the DVR reboots automatically.

USB UPGRADE

① Download the firmware of the DVR from the VITEK web-site www.vitekcctv.com .

② Create a new folder (**This folder name should be "upgrade")** in the USB thumb drive and paste the firmware "app-xxx.bin" into the folder.

③ Connect USB thumb drive to the USB port.

④ Select USB UPGRADE using ▶◀ buttons and press SEL button. Then the APPLICATION USB UPGRADE screen is displayed.



⑤ Select CONFIRM using ▶◀ buttons and press SEL button. Then the upgrading starts automatically.





⑥ After upgrading firmware is completed, the DVR reboots automatically.

7. Network access using the Exclusive network viewer

The DVR provides a live remote monitoring feature. Remote monitoring requires installation of the network viewer on your PC.

NOTICE

In a high bandwidth network, a maximum of four users can access one DVR simultaneously. In a low bandwidth network it is recommended that only one user access the DVR at a time.

7-1. PC requirements

- CPU: Intel Pentium 1.2Ghz or higher
- Memory: 256MB (512MB or higher is recommended.)
- VGA memory: 16MB (64MB or higher is recommended.)
- Resolution: 1024x768
- O/S: Windows 2000, XP Professional, XP home
- Direct X: DirectX 8.1 or higher

7-2. Installing the network viewer

1. Insert the provided CD in the CD drive and double-click "UMSClient(XXXX)**.exe**"

2. Select a destination folder and click "Next".


InstallShield Wizard
Choose Destination Location
Select folder where Setup will install files.
Setup will install Network Client in the following folder.
To install to this folder, click Next. To install to a different folder, click Browse and select another folder.
Destination Folder
C:\Program Files\DVR\Network Client
Browse...
InstallShield
< Back
Next >
Cancel

3. Select the type and click "Next".



4. Select the program folder and click "Next".

5. The setup status screen is displayed.





6. After the installation is completed, **"UMS Client"**

icon is displayed on the desktop.

7-3. Live monitoring mode and functions.



Button	Function	Description
	DATE & TIME	Displays the current date and time.
	CONNECT/DISCONNECT	Connect/disconnect network connection..

	SEARCH	Switches the live mode to search mode.
	DISPLAY MODE	Select a channel and screen display mode.
	**PAN/TILT/ZOOM/ FOCUS**	Control the PAN/TILT/ZOOM/FOCUS features on the remote camera.
	CAPTURE	Capture a still image from live screen.
	PLAY/PAUSE	Play/pause live video.
	ALARM	The ON/OFF button of the alarm output of the DVR. When an alarm of the DVR is output, this button becomes Red.
	SETUP	Display the setup screen of the network viewer.
	HDD USAGE	DVR HDD storage Indicator.
	NETWORK BANDWIDTH	Shows the transferred frames and network bandwidth.
	AUDIO	Adjust the volume. The audio can be turned on or off by clicking the audio icon.
	**LOG WINDOW**	

Operations of the display mode of the main screen

- Single channel display - Click the one of channel buttons or double-click the channel screen.



- QUAD/-screen display - Click the QUAD button to switch to quad-screen display

■ Full screen display - Click the maximize button to display only video and hide the operation panel.

Image capture of live screen

Still-image of live screen can be captured and saved as BMP or JPEG file.

1. Click the channel to be captured. Then the channel screen is surrounded with a red line.
2. Click the CAPTURE button. Then the IMAGE CAPTURE dialog is displayed.



3. Set the conditions and click OK button. Then still-image is saved.

7-4. Bi directional audio

The **UMS Client allows for bi directional audio between the client and a DVR unit. On the PC, to use bi directional audio, you will need a sound card capable of handling a microphone and speakers. On the DVR side, you will need to connect a microphone to the audio in connection, and a pair of amplified speakers to the audio out connection.**

7-5. Remote search mode and functions



Button	Function	Description
	**DATE & TIME**	Displays the recording time of the data selected on the time bar at the bottom of the main user interface.
	DISCONNECT	Disconnect network connection.
	LIVE	Switches the search mode to live mode.
	**CAPTURE**	Capture a still image from live screen.
	MARK IN	Set the start time for video backup.
	MARK OUT	Set the ending time for video backup.
	BACKUP	Backup the selected recorded video as AVI format.

	SEARCH CALENDAR	The calendar shows dates with recorded video in light blue and the selected date in dark blue.
	**TIMELINE BAR**	The timeline shows recorded data in dark blue on the bar.
	PLAYBACK BUTTON	The playback buttons.
	DISPLAY MODE	Select a channel and screen display mode.

Searching and playing video from the remote DVR/Client

Video recorded in the remote DVR or Video recorded on the PC can be searched and played back.

1. Connect the network to the remote DVR and press SEARCH button. Then the mode is changed from the live mode to the search mode.

- Searching the video recorded on the remote DVR: Connect the network to the DVR..
- Searching the video recorded in the PC: Do not connect the network to the DVR.

2. Select the date to search the video.

3. Drag the slide on the time scale and drop it between 0 to 24.

4. Press the PLAY button. Then the video recorded on the remote DVR is played back.

Backup of video on the remote DVR

Video recorded on the remote DVR can be backed up on the PC HDD as AVI format.

1. Connect the network to the remote DVR and play the video recorded in the remote DVR.
2. Drag the slide on the time scale and drop to the start time for video backup and press the MARK IN button.

3. Drag the slide on the time scale and drop to the end time for video backup and press the MARK OUT button. Then the marked time is displayed in dark green.

4. AVI Backup dialog is displayed. Click the OK button. Then the marked video is backed up.



- Start time / Stop time: Backup time can be changed.
- File path: Shows the folder that the backup file is recorded.
- Channel: Shows backup channel.

7-6. PC System configuration

Click the SETUP button. Then the Setup dialog is displayed.



Setting General

Set security options, save path, and Automatic reconnection.



- **Security Option**: Set a password for security options. When you access any of the selected functions, you will need to enter the password.
- **Save Path**: Specify the location to record for backup and still image capture.
- **Automatic reconnection**: If a user selects this function, the client S/W will automatically try to connect to the previously connected IP address if the network connection is lost.

- **Display network statistics**: If a user selects this function, the client S/W will display network status, Bit rate and Frame rate.
- **Time Format**: Change the time format mode on the Client software display.

Setting Site

The remote DVRs can be added, modified, and removed.



Setting Event

Set the record path and the size of local disk space for the log files.



- LOG – Select to save event log into 'log file'.
- ICON – Select to display the event on live video.
- EVENT LIST – Select to show the event in the 'Event List" window of live mode.

Search and check the recorded log data.



Setting Record

Set the recording conditions and select channels to record.



Select the local disk to use and the amount of disk space you want to allow the program to use for recording.



Setting Video

Set the video screen.



Setting Language

Select the language of the network client viewer.



8. Network – By a web-browser viewer

The DVR provides a live remote monitoring feature by web-browser viewer.

1. Check the IP address of the DVR from SETUP>SYSTEM>DESCRIPTION>IP ADDRESS.



2. Input the IP address or Domain name address that you pre-registered on www.vitekddns1.com on the address field and press “Go”.

3. Click this bar. Then the dialog box is displayed.

This website wants to install the following add-on: VITEK-WebViewer.cab' from 'VITEK INDUSTRIAL INC.'. If you trust the website and the add-on and want to install it, click here...

4. Click “Install” to download ActiveX control.


Internet Explorer - Security Warning
Do you want to install this software?
Name: VITEK-WebViewer.cab
Publisher: VITEK INDUSTRIAL INC.
More options
Install
Don't Install
While files from the Internet can be useful, this file type can potentially harm your computer. Only install software from publishers you trust. What's the risk?

5. Web Browser Viewer is displayed as bellow.



6. Click CONNECT button on the Left upper corner of web-viewer. Then “Connect” dialog is displayed. Enter IP address (or Domain name address that you pre-registered on

www.vitekddns1.com), Port number and Password and click “Connect”



- Server address: Input IP address of the DVR from SETUP>SYSTEM>DESCRIPTION>IP ADDRESS or Domain name address that you pre-registered on www.vitekddns1.com
- Port: Input Port number (The number sets on SETUP>NETWORK>PORT)
- Password: Input Password (The number sets on SETUP>SYSTEM>NETWORK PASSWORD

7. Then the cameras connected to the DVR are displayed on the screen.

APPENDIX: How to connect to a network

A. How to set the IP address of the DVR and open the TCP port of the router?

The port forwarding is dependant on the brand and model of the router. The port forwarding is required to allow access to the DVR beyond a router.

1. Connect network cable between DVR and Router or ADSL modem.



2. Default network setting on DVR are
   - Port: 5445
   - WEB Port : 80
   - Network : DHCP

3. From PC connected in the same Router, find IP address, Gateway, and Subnet mask by IPCONFIG command in command prompt.




C:₩WINDOWS₩system32₩cmd.exe
C:₩>ipconfig
Windows IP Configuration
Ethernet adapter Local Area Connection:
Connection-specific DNS Suffix . :
IP Address. . . . . : 192.168.0.101
Subnet Mask . . . . . : 255.255.255.0
Default Gateway . . . . . : 192.168.0.1
C:₩>

4. But if IP is something else like 192.168.x.xxx., you should change IP address, Subnet, Gateway on the DVR. Go to SETUP>NETWORK>LAN of the DVR and change the IP settings to be like IP: 192.168.XXX.XXX and Gateway: 192.168.XXX.XXX. (Refer to the user's manual of Router.)



5. Open your web browser. Enter the router IP address in the address bar (The router IP address are different with the brand and model.), click GO.

6. Enter the user name and password (**admin** is default) and press the **OK** button.

7. Select the Port Range Forwarding tab.



8. Enter each field.
   i. Application: Enter a description of the DVR (Example: store1)
   ii. Start: Enter the first number of the port you need to port forward (Example: 5445)
   iii. End: Enter the last number of the port you need to port forward (Example: 5445)
   iv. Protocol: Select Both.
   v. IP address: Enter the IP address of the DVR on SETUP>NETWORK>LAN>IP ADDRESS.
   vi. Enable: Check the enable box.
9. Select the Save settings button located on the bottom of the window. Then Port forwarding is finished.



You can learn how to port forward many kinds of Routers from the bellow site.

http://www.portforward.com/english/routers/port_forwarding/routerindex.ht

B. How to access DVR from Remote PC?

■ **LAN Connection – Using a switching hub**

Connect to the system, using a hub (Switching hub) and an Ethernet cable (10BASE-T/100BASE-TX CAT 5 LAN cable)



IP Router or HUB

1. Run the pre-install the network client software on the supplied CD. (Refer to Chapter 6. Network access using the Exclusive network viewer)
2. Check the IP address from SETUP>SYSTEM>DESCRIPTION of DVR.
3. Run network client software and click the CONNECT button.





4. Input IP address, Port No., and Password on the connect window. And click OK.

■ **Internet (ADSL) Connection using DDNS**

Connect to the system, using an Router or ADSL modem and an Ethernet cable (10BASE-T/100BASE-TX CAT 5 LAN cable)



1. Go to SETUP>NETWORK. Set NETWORK TYPE as DHCP and DDNS SERVER as ON. And make sure that DDNS SERVER NAME is vitekddns1.com
2. Go to Setup menu of Router and open TCP port 5445 using Port Forwarding. (Refer to A. How to set IP address of the DVR and open TCP port of the router?)
3. Confirm the Mac address and Serial No. from the label of the rear panel of the DVR.
4. Open the web browser and log on to http://www.vitekddns1.com



- MAC Address: Input the Mac address (EX. 0002690XXXXX) without a space.
- Serial Number: Input the Serial No. (EX. 43000700XXX) without a space.
- Domain Name: Input Domain Name for your DVR system (Note. Input only Domain Name and never input “vitekddns1.com”.)

5. Click the DUPLICATION CHECK button to see if the domain name is available.
6. If you see the screen “You can use the Domain name you entered” then click RETURN and click REGISTER button to complete the registration.
7. Run the pre-install the network client software on the supplied CD. (Refer to Chapter 6. Network access using the Exclusive network viewer)
8. Click button and add the DVR as necessary.





- Site Name: Input the name of the DVR.
- IP Address: Input the Domain Name that is registered on http://www.vitekddns1.com (EX. XXXXX.vitekddns1.com)
- Port Number: Input the port number.
- Protocol: Select TCP.
- Password: Input the network password.

9. Click CONNECT button. Then the Connect window is displayed.



10. Select the site that you want to access and click OK.

28492 CONSTELLATION ROAD VALENCIA, CA 91355
WWW.VITEKCCTV.COM | 888-VITEK-70